

1. The Main Power switch must be on, with the Sub-Power (front panel) switch off.
2. Press the following keys in order :
DOWN, RIGHT, LEFT, UP, RIGHT, DOWN and LEFT
3. Then, within 5 seconds, press the LEFT, RIGHT and DOWN keys while turning on the Sub-Power switch.
4. If done correctly the unit will turn on and the front panel will display "Service Mode".
5. If the front panel displays "Service Mode is protected", please shut off the Sub-Power switch and try again.