

- Be sure to switch OFF the Main Power before attempting to clean the print elements.
- Use the black cleaning pen on the head gear according to the diagram below.
- Wipe the alcohol pen tip on the right edge of the print head.

