

JV33-130/160 補足説明書

このたびは、JV33 シリーズをお買い上げいただき誠にありがとうございます。
ファームウェア Ver.4.0 より、次の機能が追加になりました。
本書をお読みになり、十分理解してからご使用ください。

インクを変更したいとき

お使いになっているインクの種類や色を変えることができます。



- 「4色モデル」から「6色モデル」にするなどインクセットを変更したい場合は、サービスマンによる作業が必要です。弊社サービスまたは販売店にお問い合わせください。

インク種類を変更する

ES3 インクから SS21 インクに変更したい場合など、お使いのインク種類を変更するときは、次のようにしてください。

インクカラーを変更する

SS21 インクの「6色」と「6色+白」を切り替えたい場合など、お使いのインクカラーを変更するときは、次のようにしてください。

装置に残っているインクの「排出」とヘッドやチューブの「洗浄」を行う

JV33-130/160 取扱説明書 4章「ハイシュツ&センジョウ」を参照してください。

インクの充填を行う

JV33-130/160 取扱説明書 4章「インクの初期充填を行う」を参照してください。

重要！ インク種類変更の注意事項

現在お使いのインク種類によっては、変更できるインク種類に制限があります。右の表を確認してください。

		変更したいインク種類	
		PIG	Sb51/Sb52
現在のインク種類	PIG	変更できます	弊社サービスまたは販売店にお問い合わせください
	Sb51/Sb52		
	SS21/ES3	変更できません	変更できます

インクカラー変更の注意事項

SS21 の白インクを「SS21W」から「SS21W-2」に交換する場合は、別紙『新白インク (SS21W-2) をお使いになる前に (D201848)』に従って作業を行ってください。

洗浄を行うには、専用の洗浄液カートリッジ (別売) が必要です

現在お使いのインク種類に合った洗浄液カートリッジを使って洗浄を行ってください。

インクの種類	洗浄液の種類
ソルベントインク (SS21/ES3)	MILD SOLVENT 洗浄液カートリッジ (SPC-0294)
水性顔料インク (PIG)	水性洗浄液カートリッジ (SPC-0259)
昇華転写インク (Sb51/Sb52)	

インクカートリッジと MBIS1 を混在時のインク供給経路の切替

4色インクセットで、同色の供給経路にインクカートリッジとオプションのバルクインクシステム (MBIS1) を混在して使用している場合、優先して使用するインクを選択できます。



- 通常、同色のインク供給経路にインクカートリッジとバルクインクシステム (MBIS1) を混在して使用する場合、バルクインクシステム (MBIS1) 側のインクを優先して使用します。

重要！

- 本機能は4色インクセットをお使いの場合のみ有効です。
- インクカートリッジとバルクインクシステム (MBIS1) が混在している供給経路がない場合は、本機能は設定できません。
- 本機能で選択しているカートリッジを引き抜くか電源を入れ直すと設定は無効となります。

1

ローカルまたはリモートモードで、**ENTER** キーを押す

ES3-インク MMCCYYKK
サンリョウ 34567899

2

REMOTE キーを押す

BULK/CART センタク
- B B B

現在、供給している側を表示
B : バルクインクシステム (MBIS1)
C : インクカートリッジ
- : 混在していない

3

▲ ▼ ◀ ▶ を押して、供給経路と、どちらを優先するか設定する

BULK/CART センタク
- C B B

経路の選択 : **◀ ▶** で選ぶ
優先する側を設定 : **▲ ▼** で入力

4

ENTER キーを押す

- ローカルまたはリモートモードに戻ります。

JV33-130/160

Supplement for the Basic Operation manual

Thank you very much for your purchase of the JV33 series.
The following functions are added from firmware version 4.0.
Please read this manual and fully understand it before using the device.

Changing the ink

Ink type or the color used can be changed.



- To change the ink set such as changing from "4-color model" to "6-color model", the machine must be worked by our service engineer. Contact our service office or the distributor in your region.

Change the ink type

To change the ink type used such as changing from ES3 ink to SS21 ink, work as follows.

Change the ink color

To change the ink color used such as changing from "6-colors" to "6-colors + white" of SS21 ink, work as follows.

"Discharge" the remaining ink in the machine, and "Wash" the head or the tube. See JV33-130/160 Operation Manual Chapter 4 "DISCHARGE & WASH".

Fill ink. See JV33-130/160 Operation Manual Chapter 4 "Initial ink fill up".



- Note for changing ink type**
Changeable ink type is limited by the type of ink used. See the table on the right.

	Ink type used	Ink type to be changed		
		PIG	Sb51/Sb52	SS21/ES3
	PIG	Changeable	Contact our service office or the distributor in your region.	Changeable
	Sb51/Sb52			
	SS21/ES3	Not changeable	Changeable	

- Note for changing ink color**
To replace white ink of SS21 from "SS21W" to "SS21W-2", follow the exhibit "Before using new White Ink (SS21-W2)" (D201848).
- When washing, use a special cleaning solution cartridge (sold separately).**
Wash with the proper cleaning solution cartridge for the used ink type.

Ink Type	Cleaning Solution Type
Solvent ink (SS21/ES3)	MILD SOLVENT Cleaning Solution Cartridge (SPC-0294)
Aqueous pigment ink (PIG)	Aqueous cleaning solution cartridge (SPC-0259)
Sublimation dye ink (Sb51/Sb52)	

Switch setting of ink supply path when both ink cartridge and MBIS1 are set

When both an ink cartridge and the optional bulk ink system (MBIS1) are set in the supply paths of the same color for 4-color ink set, you can select the ink to be used first.



- Usually, when both an ink cartridge and the bulk ink system (MBIS1) are set in the supply path of the same color, the ink in the bulk ink system (MBIS1) is used first.



- This setting is only available for 4-color set.
- If supply path does not have both ink cartridge and the bulk ink system (MBIS1), this function cannot be set.
- Pull out the ink cartridge selected on this function or turn the power on again to disable the setting.

- Press the **ENTER** key in the LOCAL or the REMOTE mode.

ES3 - INK MMCCYYKK
 REMAIN 34567899
- Press the **REMOTE** key.

BULK / CART SELECT
 - B B B

Displays the currently supplying ink.
B : Bulk ink system (MBIS1)
C : Ink cartridge
 - : Only one type is set
- Press the **▲ ▼ ◀ ▶** key to set the supply path and the ink to be used first.

BULK / CART SELECT
 - C B B

Select the supply path : Press the **◀ ▶** key.
 Select the ink to be used first : Press the **▲ ▼** key.
- Press the **ENTER** key.

 - It enters in the LOCAL or the REMOTE mode.