

4-10 Making the Network Settings

Setting the IP Address, Subnet Mask, Etc.

Procedure


- 1


MENU

SYSTEM INFO.

◀▶

▶

Press .


Press  several times.
- 2


SYSTEM INFO.

NETWORK

◀▶

▶

Press .


Press .
- 3



NETWORK

IP ADDRESS

◀▶

▶

Press .

Use   to choose the item whose setting you want to make.
- 4


IP ADDRESS



000.000.000.000

◀▶

▶

↵

Press  twice.

Use   to select the address number.
- 5


IP ADDRESS

192.000.000.000

◀▶

▶

↵

Press .
- 6

IP ADDRESS


192.168.000.003

◀▶

▶

↵

Repeat **4** and **5** to set all the address numbers.


When you have finished making the setting, press .
- 7

W1200mm

SETUP SHEET

◀▶

▶

Press  to go back to the original screen.

Description

Make sure the machine is connected to the network by an Ethernet cable.
For detailed information about the settings, consult your network administrator.

[IP ADDRESS]: IP address
[SUBNET MASK]: Subnet mask
[GATEWAY ADDR.]: Gateway address